



A&M



## **SIMPLE Garden Jacuzzi**

# **USER MANUAL**

**A&M. Rzepa I Wspólnicy Spółka Jawna**



ul. Szkolna 98  
32-641 Przeciszów

NIP: PL 5492440516  
[en.domkisauny.pl](http://en.domkisauny.pl)

888 768 211  
[biuro@domkisauny.pl](mailto:biuro@domkisauny.pl)





A&M

## USER MANUAL

*Garden jacuzzi model: SIMPLE*

### Table of Contents

1. Before first use:.....	3
2. Bathing:.....	4
3. Hygiene:.....	5
4. Operating instructions:.....	6
5. Controls: .....	7





A&M

## USER MANUAL

*Garden jacuzzi model: SIMPLE*

### 1. Before first use:

- It is **recommended to treat the external wooden surface** of the jacuzzi with a weather-resistant wood **impregnation** product suitable for outdoor use.
- Place the jacuzzi on a **hardened and leveled** surface.
- Fill the tank up to a maximum of **3/4 of its height**.
- During heating, **cover the jacuzzi with a lid** to prevent heat loss.





A&M

## USER MANUAL

### *Garden jacuzzi model: SIMPLE*

## 2. Bathing:

- Ensure that your health condition allows safe use of the jacuzzi.
- Do not use the jacuzzi while under the influence of alcohol, drugs, or strong medication.
- Make sure that using the jacuzzi does not pose a risk to you or others nearby.
- Never leave children unattended near the jacuzzi.
- For safety reasons, enjoy hot baths in the presence of other people.
- Do not leave sick, disabled individuals, or children unattended during bathing.





A&M

## USER MANUAL

*Garden jacuzzi model: SIMPLE*

### 3. Hygiene:

- Maintain water hygiene using widely available water care and disinfection products.
- Regularly replace the water depending on its current condition.





## USER MANUAL

*Garden jacuzzi model: SIMPLE*

### 4. Operating instructions:

- **Do not allow water in the jacuzzi to freeze**, as it may damage the basin, water system, and accessories. In low outdoor temperatures, use brine, keep the water heated, or completely empty the tank.
- During severe frost, if it is impossible to maintain water at a positive temperature, empty the tank and system to prevent freezing and damage.
- To completely remove water from the system at the final stage of emptying, turn on the aeration system for a few seconds to expel all water from the circuit.
- Running the pump without water for an extended time can damage it!
- Heat the water to a maximum of 40°C; higher temperatures can deform the liner, and bathing at higher temperatures is harmful to health.
- The heater is equipped with a flow switch that activates when water is flowing.





A&M

## USER MANUAL

*Garden jacuzzi model: SIMPLE*

### 5. Controls:

- The jacuzzi is equipped with 10 water-air jets controlled by a pneumatic button and a dial.
- Air is drawn into the jets from a suction valve located on the upper edge of the tub.  
The valve can be adjusted to increase or decrease the air (via the dial on the panel).
- The pneumatic button activates the water pump, turning on the hydromassage.
- The 3kW heater is located in the water circuit supplying the jets. ***To activate the heater: Set the temperature on the dial located directly on the heater and turn on the water pump.***
- The water circuit is activated using the pneumatic button.
- The LED lighting switch is also located on the housing. Color changes occur with each subsequent press of the button

